



**Modular Wall
systems**

SPECIFICATION

PREMIUM GRADE EXTERIOR PAINT- Dulux Weather Shield or similar Guide only

NOTE: This guide is for paint-on finishes only. If a trowel on render effect is going to be applied you can consult your local MWS agent or watch the MWS instructional DVD for a complete guide to applying render.

*We recommend you paint your wall **within 90 days of installation.***

OVERVIEW

Substrate	Modular Wall Systems Fibre cement panels
Paint type	Dulux Weather Shield or similar
Preparation required	None –clean and dry and free of contaminants
Coats required	2

Substrate	Modular Wall Systems Posts & Trims
Paint type	Dulux Weather Shield or similar
Preparation required	Scuff primed surface with a scotch bite pad (as per installation instructions), clean and dry and free of contaminants
Coats required	2

SURFACE PREPARATION

The surface to be painted must be clean, dry and free of contaminants including oxidization.

Repair any damaged area/s with appropriate filler, sand smooth and dust down prior to the application of paint. Lightly scuff any primed metal components with a scotch bite pad. This is explained in detail in the installation instructions.



APPLICATION

We recommend applying the first coat with a roller. Cut in the sections that the roller missed with a brush prior to applying the second coat. Let the first 'cutting in' dry and apply a second 'cutting in' coat prior to the second and final roller coat.

On a large job a spray application maybe justified. Please see the paint manufacturer for advice on spray application.

Note: Surface preparations should remain the same for both roller and spray applications.